

SET	k
100	2,4
125	3,6
160	6,7
200	11,1
250	16,6
315	27,2
400	45,2

Säätö - suuttimen tulppaus: $k=-0,2$
Injustering - pluggning av 1 dysa: $k=-0,2$
Adjustment - plugging 1 nozzle: $k=-0,2$

